

DOC'S BLOCKS
AUTOMOTIVE AIR CONDITIONING REPAIR

CONDENSERS

Condensers must be flushed out when ever a compressor grinds up. Even then, there is no assurance this will remove all the contamination from the condenser. Tube and fin condensers can become clogged from teflon shredding off the pistons. In most cases, flushing will not remove the blockage and the condenser will have to be replaced. The passages of an aluminium condenser are so small that flushing will do nothing more than remove oil. The condenser would need to be replaced.

